

Maintenance Oiling and Care with Wax Oil, directly after installation before furnishing.

Maintenance oiling with wax oil:

- Make sure the surface is clean, clean with Rubio Monocoat SOAP.
- Shake the can with Rubio Monocoat Universal Maintenance Oil well so that you get with bottom sediment.
- For large surfaces: Work two and two, one applies and one removes excess, you need two single scrubbers, a layer of red and white circles. Rags for drying hands with etc.
- Use a single scrubber and red pad to apply the oil, apply thinly. Max 5-10m² at a time.
- Keep in mind that the oil is fast hardening, At + 15min it becomes tough as chewing gum, we therefore recommend that you try it figure out how many m² per time you are able to do. Chance not with too large surfaces.
- Have a bucket of water with you where you throw away oil-soaked ones rags, (this is due to the risk of fire in case of spontaneous combustion) this bucket SHOULD exit the building at the end of the shift.
- Use a single scrubber and white pad to remove the surplus. Feel free to look in the trailer light so that all the roundabout tracks are away. When the roundabout is too wet—change. You can count a roundabout per 50-75m² based on the fact that it was thinly laid from the beginning.
- Let the surface dry for at least 6-8 hours before using the surface.
- Use Rubio SOAP and water for any cleaning.

This product should also be used when cleaning the floor after inauguration.

